

# KTU5

Ultrasonic level transmitter

825B130A

## Technical Data

Housing material: **PP**  
Mechanical installation: **2" GAS M (PP flange DN80 opt.)**  
Protection degree: **IP66 / IP68 (sensor)**  
Electrical connection: **Internal plug-in connectors**  
Working temperature: **-30 ÷ +70°C; +80°C non-continuous**  
Pressure: **from 0,5 to 1,5 bar (absolute)**  
Power supply: **12, 24Vdc or 24, 115, 230Vac (specify at the order)**  
Power consumption: **2W**  
Analog output: **4 ÷ 20mA, max 750ohm**  
Relays output: **n°2 3A 230Vac (n.o.)**  
Digital communication: **MODBUS RTU**  
Max measure range: **max 0.25 ÷ 5m**  
**max 0.4 ÷ 8m**

[In case of non perfectly reflecting surfaces, the maximum distance value will be reduced]

Blind distance: **0,25m (5m vers.) / 0,40m (8m vers.)**

Temperature compensation: **digital from -30 to 80°C**

Accuracy: **±0,5% (of the measured distance)**  
**not better than ±3mm**

Resolution: **1mm**

Calibration: **2 buttons, or via VL6011 or by MODBUS RTU**

Warm-up: **5 minutes typical**

LCD Display: **Plug-in VL6011 (opt.) display/**  
**keyboard with 4 buttons and matrix LCD**



## ☐ Warranty

Products supplied by SGM LEKTRA are guaranteed for a period of 12 (twelve) months from delivery date according to the conditions specified in our sale conditions document.

SGM LEKTRA can choose to repair or replace the Product.

If the Product is repaired it will maintain the original term of guarantee, whereas if the Product is replaced it will have 12 (twelve) months of guarantee.

The warranty will be null if the Client modifies, repair or uses the Products for other purposes than the normal conditions foreseen by instructions or Contract.

In no circumstances shall SGM LEKTRA be liable for direct, indirect or consequential or other loss or damage whether caused by negligence on the part of the company or its employees or otherwise howsoever arising out of defective goods

## ☐ Factory Test Certificate

In conformity to the company and check procedures I certify that the equipment:

**KTU5**..... Production and check date: .....

Serial n. ....

is conform to the technical requirements on Technical Data and it is made in conformity to the SGM-LEKTRA procedure

Quality Control Manager .....



**Process Control and Measurement**

The non intrusive system application is now preferred in the level measurements field. For this reason the **SGM-LEKTRA** developed the **KTU5** unity to best meet the "GENERAL-PURPOSE" application requests. The **KTU5** unit offers, together with its compact size, a complete versions range that makes the **KTU5** very versatile for the most varied applications, including areas chemically aggressive environments. **KTU5** is an ultrasonic level transmitter, temperature-compensated and suitable for connection with **MODBUS RTU** acquisition systems. **KTU5** is a compact unit which in addition to an analog output includes two freely addressable relay (only 4 wires vers.).

☐ **Non-contact level measurements**

☐ **Suitable for liquids and granulates level measurement**

☐ **Integrated digital temperature sensor to compensate the measure**

☐ **MODBUS RTU com. protocol**

☐ **12,24Vdc o 24, 115, 230Vac power s.**

☐ **Mechanical protection: IP66 / IP68 (sensor)**

☐ **Output: 1 4÷20mA analog output  
2 relays output (4-wires vers.)**

## 1. SAFETY



### 1.1 Installation precaution

- Installation shall only be performed by qualified personnel and in accordance with local governing regulations.
- Make sure that the working temperature is between -30 and +70 ° C, +80 ° C non-continuous
- Install the transmitter in a its physical characteristics and housing/sensor construction materials compatible environment.
- The transmitter must be used safety warnings observance.
- Improper transmitter use would cause serious damage to people, to the product and connected equipment.


## 2. INSTALLATION

### 2.1 MECHANICAL DIMENSIONS

The KTU5 transmitter has the 2 "GAS M threaded, equipped with n. 2 2" BSP/ PP fixing bolts. DN80 PN6 UNI 1092-1/PP flange is available (optional accessory).




### 2.2 Mounting examples



## 2.3 Mounting precautions

### 2.3.1 Mounting position (Fig.7)

- With cambered roof, Do not install the sensor in the tank center (b). Leave a 300mm minimum distance between the sensor and the tank smooth wall (d).
- Use a protective cover to protect the sensor from weather and direct sunlight (c).
- Do not install the sensor near the load zone (a).
- Make sure that in the sensor emission beam (lobe) there are no obstacles (f,s) that can be intercepted as level.
- Make sure that there is not foam presence on the product surface to be measured




	Lobe	L	r
KTU5 5m	10°	5m	0.5m (5m)
KTU5 8m	10°	8m	0.8m (8m)

Tab.1

### 2.3.1 Blind distance

During installation is important to remember that in the sensor vicinity there is a blind zone (or **BLIND DISTANCE**) of 0.25m (for 5m max **KTU5** range) or 0.4m (for 8m max **KTU5** range) where the sensor can not measure.


Fig.8



### 2.3.2 Installation in nozzle

Installing the **KTU5** sensor in a nozzle (see fig.9), make sure the sensor bottom protrudes at least 10 mm from the bottom nozzle

Fig.9




**KTU5** can be installed in an extension pipe (see Figure 10) to turn away the sensor from the maximum level point. The extension pipe must be flat and without joints (welds, etc..), also, the pipe terminal part must be cut at 45° and with the borders without burr.

KTU5 5m		KTU5 8m	
D (mm)	L max. (mm)	D (mm)	L max. (mm)
57	80m	80	240
80	240	100	300
100	300		

Tab.2

Fig.10



### 2.3.4 Reference pipe installation

Disturbing factors that may influence the level measurement in liquids, as for example:

- foam presence on the product surface (Fig.11)
- internal structures presence in the tank (Fig.12)
- presence on the liquid surface of floating bodies (Fig.13)

can be avoided with the use of level measurement inside of pipes (by-pass pipe or calm pipe with 57mm min. diameter) The pipe must have a length greater or equal than the empty distance, also, must have some of vent holes (Fig. 13-A) to allow the pipe regular filling and emptying.

In the programming menu, to the **"PRODUCT"** parameter, must select the **"LIQUID PIPE"** option (see page 9 or 15)

Fig.11




Fig.12




Fig.13





Fig.13A



## 2.3.5 Agitators presence

The level measurement is possible thanks to the **Auto-Tuned** statistical filter. Should rarely need to adjust the filter setting by editing 2 **KTU5** sensor programming parameters:

- **FILTER**; this parameter is present in the **Quick Setup** menu (page 9) and in the Advanced Configuration "**SETUP**" menu (page 16); increasing the parameter value, decreases the sensor sensitivity to the level measurement sudden variations.
- **F-WINDOW**; this parameter is present in the Advanced Configuration "**SERVICE**" menu (page 26); decreasing the parameter programmed value, increases the sensor immunity to false echoes.



## 2.3.6 Mechanical installation accessories




Fig.15

## 3. CONNECTIONS

### 3.1 Wiring

- 1) Separate the engine control cables or power cables from the **KTU5** connection cables..
- 2) Open the cap by unscrewing.
- 3) Lead the cables into the transmitter through the glands.
- 5) Close the cap and tighten the cable glands.






Fig.16

The immunity to electromagnetic interference complies with  $\text{CE}$  Directives

## 3.2 Humidity infiltrations

To avoid the humidity infiltration inside the housing is recommended:

- for electrical connections, use a cable with a 5÷10mm outer diameter and fully tighten the M16 cable gland
- fully tighten the cap
- position the cable so that it forms a downward curve at the M16 output (Fig. 17); in this way the condensation and/or rain water will tend to drip from the curve bottom




Fig.17

## 4. CONFIGURATION MODES

The **KTU5** have 3 configuration/calibration modes:

- via digital communication:  
via **MODBUS RTU**, by PC
- via 2 on board buttons
- via **VL611** programming module

### 4.1 Via MODBUS RTU

#### 4.1.1 MODBUS RTU PC connection (fig.21)

- 1) KTU5 with MODBUS RTU communication protocol
- 2) USB/RS485 interface module, cod.694A004A
- 3) MODBUS RTU communication S/W, cod.010F105A for KTU5 transmitter

With this software is possible:

- connect, by selecting the UID address, the KTU5 transmitters in MODBUS RTU network
- read on your PC monitor all measures in reading and KTU5 operation data
- programming all KTU5 configuration parameters
- storing on files, data logger function; KTU5 measures in reading and operating states




Fig.18

## 4.2 Via 2 BUTTONS calibrations

**KTU5** has 2 buttons on board (fig.19), **P1** and **P2**, with which it is possible:

- to program the level measurement range via the **4mA** and **20mA** distances self-acquisition
- to program the **RL1** and **RL2** thresholds via the switching distances self-acquisition.




Fig.19

### 4.2.1 4mA DISTANCE (fig.20)

To set the **0%** level measurement (4mA) it is necessary that the real level is that corresponding to the “**4mA Dist.**”; alternatively it is possible to place a target orthogonally to the **KTU5** transmitter at a distance equivalent to the **0%** level. Wait until the **ECO** LED (fig.16) flashes for at least 30s, press simultaneously **P1** and **P2**, release them and verify that the **ECO** LED (fig.16) remains turned on. Press **P1** two times and wait for the **ECO** LED (fig.16) flashes. The distance has been saved and automatically associated with the **0%** level (4mA).

### 4.2.2 20mA DISTANCE (fig.20)

To set the **100%** level measurement (4mA) it is necessary that the real level is that corresponding to the “**20mA Dist.**”; alternatively it is possible to place a target orthogonally to the **KTU5** transmitter at a distance equivalent to the **100%** level. Wait until the **ECO** LED (fig.16) flashes for at least 30s, press simultaneously **P1** and **P2**, release them and verify that the **ECO** LED (fig.16) remains turned on. Press **P2** two times and wait for the **ECO** LED (fig.16) flashes. The distance has been saved and automatically associated with the **100%** level (4mA).

### 4.2.3 RL1 MAX LEVEL THRESHOLD DISTANCE (fig.20)

To set the **RL1** maximum level alarm threshold is necessary that the real level is that corresponding to the “**RL1 max. lev. threshold dist.**”; alternatively it is possible to place a target orthogonally to the **KTU5** transmitter at a distance equivalent. Wait until the **ECO** LED (fig.16) flashes for at least 30s, press simultaneously **P1** and **P2**, release them and verify that the **ECO** LED (fig.16) remains turned on. Press **P2** and then **P1** and wait for the **ECO** LED (fig.16) flashes. The distance has been saved and automatically associated with the **RL1** threshold (see default level alarm threshold settings on page 10)

### 4.2.4 RL2 MIN LEVEL THRESHOLD DISTANCE (fig.20)

To set the **RL2** maximum level alarm threshold is necessary that the real level is that corresponding to the “**RL2 min. lev. threshold dist.**”; alternatively it is possible to place a target orthogonally to the **KTU5** transmitter at a distance equivalent. Wait until the **ECO** LED (fig.16) flashes for at least 30s, press simultaneously **P1** and **P2**, release them and verify that the **ECO** LED (fig.16) remains turned on. Press **P1** and then **P2** and wait for the **ECO** LED (fig.16) flashes. The distance has been saved and automatically associated with the **RL2** threshold (see default level alarm threshold settings on page 11)





Fig.20

## 4.3 via VL611 configuration

The **VL611** programming module can be mounted and removed from the **KTU5** without affecting the unit operation. Unscrewing the cap, the **VL611** module can be connected or disconnected as shown in Fig.21. The **VL611** module is equipped with matrix LCD.

))) displayed at the bottom indicates the correct echo signal reception

! displayed at the top alerts that there is a generic error; press  to show message that indicates the present error type.  
The KTU5 returns automatically to RUN mode.













Fig.21

The **VL611** program module has 4 buttons (fig. 24) which allow to perform all operational, control and programming instrument functions.





In the configuration menus, is possible:

- Submenus and parameters access; press  to select and press  to access.
- Parameter options choice: Press  to select the option and press  to store the option.  
Press  to exit without storing
- Configure the parameter values; in some parameters the configuration is done by setting a value (eg., in the **SET DISTANCE 4mA** parameter is possible to change the the corresponding distance value, in mm): press  to select the digit to be modified (the digit is highlighted in **inverse**), press  to change the highlighted digits number, press  to save the set value and exit automatically. Press  to exit without storing .






In the display top right, during the settings, there is always a number, eg. "1.2". This number is the menu or parameter index that's displayed. The menu structure is represented on page 8 and on pages 13÷14.



Fig.22

-  - Configuration access  
- Options confirmation  
- Parameters values confirmation
-  - Parameters values selection  
- Parameters scroll
-  - Parameters values modification
-  - Exit configuration  
- Back to previous menu  
- Eco map (from RUN mode)


**With the VL611 module is possible to access two configuration modes for the KTU5 setting:**

- ☐ **QUICK START** - Menu with easy access for quick basic parameters configuration.  
To access: from "RUN" mode press  to the quick setup menu mode access,  to exit
- ☐ **ADVANCED CONFIGURATION** - Full menu with access to all parameters, including functional parameters. It is recommended to carefully read the complete documentation before accessing.  
To access: from "RUN" mode, holding down , press  to the advanced configuration mode access,  to exit







WARNING! - The documentation provided with the KTU5 contain the most frequently used indications. If it's necessary refer to the full manual, it can be downloaded from our website [www.sgm-lektra.com](http://www.sgm-lektra.com) , in the products section.

5. QUICK START MODE


From “RUN” mode press  to access the Quick Setup menu



Select the parameters by moving the cursor with , and confirm with ; press  to exit



5.1 Quick Setup menu structure





## 5.2.1 SET DISTANCE 4mA

Press **ENTER** to display the distance value associated with 4mA output.

Use **UP** and **DOWN** to modify that value; in the Fig.25 example, the 4mA distance is 3500mm. Press **ENTER** to confirm.

SET DISTANCE 4mA 0  
SET DISTANCE 20mA  
MEDIUM  
FILTER COEFFICIENT  
BLIND DISTANCE  
RL1 THRESHOLD  
RL2 THRESHOLD  
DISPLAY

SET DISTANCE 4mA 0.1  
**3500** mm

## 5.2.2 SET DISTANCE 20mA

Press **ENTER** to display the distance value associated with 20mA output.

Use **UP** and **DOWN** to modify that value; in the Fig.25 example, the 20mA distance is 500mm. Press **ENTER** to confirm.

SET DISTANCE 4mA 0  
SET DISTANCE 20mA  
MEDIUM  
FILTER COEFFICIENT  
BLIND DISTANCE  
RL1 THRESHOLD  
RL2 THRESHOLD  
DISPLAY

SET DISTANCE 20mA 0.2  
**0500** mm

## 5.2.3 MEDIUM

Press **ENTER** to display the previous setting

Press **UP** to select the medium type.  
Press **ENTER** to confirm.  
In fig.26 product selection example.

SET DISTANCE 4mA 0  
SET DISTANCE 20mA  
MEDIUM  
FILTER COEFFICIENT  
BLIND DISTANCE  
RL1 THRESHOLD  
RL2 THRESHOLD  
DISPLAY

MEDIUM 0.3  
SOLIDS  
LIQUIDS  
LIQUIDS PIPE

## 5.2.4 FILTER COEFFICIENT

Press **ENTER**. Increasing the value slows down the sensor response speed.

Use **UP** and **DOWN** to modify the value. Input a value from 1 to 99. Press **ENTER** to confirm.  
In fig.27 value choice example.

SET DISTANCE 4mA 0  
SET DISTANCE 20mA  
MEDIUM  
FILTER COEFFICIENT  
BLIND DISTANCE  
RL1 THRESHOLD  
RL2 THRESHOLD  
DISPLAY

FILTER COEFFICIENT 0.4  
**20**

## 5.2.5 BLIND DISTANCE

Press **ENTER**. The **BLIND ZONE** is used to avoid undesired measures near to the transmitter

Use **UP** and **DOWN** to modify the value. Press **ENTER** to confirm. The minimum value is 250mm (5m max vers.) or 400mm (8m max vers.).

SET DISTANCE 4mA 0  
SET DISTANCE 20mA  
MEDIUM  
FILTER COEFFICIENT  
BLIND DISTANCE  
RL1 THRESHOLD  
RL2 THRESHOLD  
DISPLAY

BLIND DISTANCE 0.5  
**0250** mm




Fig.23




Fig.24




Fig.25




Fig.26

## 5.2.6 RL1 THRESHOLD

Press **ENTER** to display the previous setting. Set the distance from the sensor

SET DISTANCE 4mA 0  
SET DISTANCE 20mA  
MEDIUM  
FILTER COEFFICIENT  
BLIND DISTANCE  
► RL1 THRESHOLD  
RL2 THRESHOLD  
DISPLAY

Use **←** and **→** to modify the value; in the Fig.29 example the RL1 max. level threshold distance is 700mm.

Press **ENTER** to confirm.

**NB**-RL1 inactive with 0000mm

VALUE 0.6  
**0700mm**




Fig.27

When confirming with the **ENTER** button the maximum level threshold value storage, in the example 700m (figures 29 and 30), the **KTU5** activates RL1 with the following default settings for level alarm threshold:

- 1) MIN / MAX = MAX; maximum level alarm
- 2) DELAY = 0 sec.; no switching delay
- 3) SECURITY = YES; relay de-energized, and contact open, during the maximum level alarm
- 4) ENABLE / DISABLE = ENABLE; alarm threshold function enabled

To change these relay settings is necessary to access the advanced setup menu (pag.16) and any subsequent changes to the RL1 threshold value not affect the relay custom settings.




Fig.28

## 5.2.7 RL2 THRESHOLD

Press to display the previous setting. Set the distance from the sensor

Use and to modify the value; in the Fig.31 example the RL2 min. level threshold distance is 3000mm.

Press to confirm.


**NB**-RL2 inactive with 0000mm

SET DISTANCE 4mA 0  
SET DISTANCE 20mA  
MEDIUM  
FILTER COEFFICIENT  
BLIND DISTANCE  
RL1 THRESHOLD  
▶ RL2 THRESHOLD  
DISPLAY

VALUE

0.7

**3000mm**



When confirming with the button the maximum level threshold value storage, in the example 3000mm (figures 31 and 32), the **KTU5** activates RL2 with the following default settings for level alarm threshold:

- 1) MIN / MAX = MIN; minimum level alarm
- 2) DELAY = 0 sec.; no switching delay
- 3) SECURITY = YES; relay de-energized, and contact open, during the maximum level alarm
- 4) ENABLE / DISABLE = ENABLE; alarm threshold function enabled

To change these relay settings is necessary to access the advanced setup menu (pag.16) and any subsequent changes to the RL2 threshold value not affect the relay custom settings.






Fig.30

## 5.2.8 DISPLAY

Press  to access the settings change.



With the  button is possible to select the data to display

Press  to confirm.




Fig.31

## 5.2 ECHO MAP

Pressing the **BK**, from RUN mode, to access directly to the echoes digital map display, which are in KTU5 receiving (Fig.34).

This function is useful for:

- properly orient the transducer pointing.
- verify the echoes in acquisition correctness.
- identify any false echo signals that may cause measurement errors.





Fig.32





**SGM-LEKTRA S.r.l.** Via Papa Giovanni XXIII, 49 - 20090 Rodano (MI) - ITALY-

tel: ++39 0295328257 fax: ++39 0295328321

web: [www.sgm-lektra.com](http://www.sgm-lektra.com) e-mail: [info@sgm-lektra.com](mailto:info@sgm-lektra.com)






## 6. ADVANCED CONFIGURATION MODE

From "RUN" mode, holding down , press  to the advanced configuration mode access

DISTANCE  
3321 mm  
LEVEL  
1679 mm




press  to select the menu and press  to access.  
Press  to exit

► SETUP  
DISPLAY  
DIAGNOSTIC  
SERVICE  
INFO




### 6.1 Advanced setup menu structure


#### 6.1.1 "SETUP" menu




## 6.1.2 “DISPLAY” menu




## 6.1.3 “DIAGNOSTIC” menu



## 6.1.4 “SERVICE” menu



## 6.1.4 “INFO” menu





## 7. ADVANCED CONFIGURATION DETAIL

### 7.1 SETUP

From "RUN" mode, holding down , press  to access

►SETUP  
DISPLAY  
DIAGNOSTIC  
SERVICE  
INFO



Select the parameters by moving the cursor with  and confirm with 

►SET DISTANCE 4mA 1  
SET DISTANCE 20mA  
MEDIUM  
FILTER COEFFICIENT  
BLIND DISTANCE  
ACTUAL LEV. 4mA  
ACTUAL LEV. 20mA  
RELAY

#### 7.1.1 SET DISTANCE 4mA

Position the ► cursor on DISTANCE 4mA, press  to enter

►SET DISTANCE 4mA 1  
SET DISTANCE 20mA  
MEDIUM  
FILTER COEFFICIENT  
BLIND DISTANCE  
ACTUAL LEV. 4mA  
ACTUAL LEV. 20mA  
RELAY

Use  and  to modify the value.

Press  to confirm.  to exit without changes

Default value: 5000mm (range 5m) or 8000mm (range 8m)



SET DISTANCE 4mA 1.1

**5000** mm

#### 7.1.2 SET DISTANCE 20mA

Position the ► cursor on SET DISTANCE 20mA, press  to enter

SET DISTANCE 4mA 1  
►SET DISTANCE 20mA  
MEDIUM  
FILTER COEFFICIENT  
BLIND DISTANCE  
ACTUAL LEV. 4mA  
ACTUAL LEV. 20mA  
RELAY

Use  and  to modify the value.

Press  to confirm.  to exit without changes

Default value: 300mm (range 5m) or 500mm (range 8m)

SET DISTANCE 20mA 1.2

**0300** mm

#### 7.1.3 MEDIUM

Position the ► cursor on MEDIUM, press  to enter

3 configurations are possible:

SOLIDS - granular solids measurement

LIQUIDS - liquids measurement

LIQUIDS PIPE - liquids measurement in pipe reference

Press  to select the product type.

Press  to confirm.  to exit without changes

Default value: LIQUIDS

SET DISTANCE 4mA 1  
SET DISTANCE 20mA  
►MEDIUM  
FILTER COEFFICIENT  
BLIND DISTANCE  
ACTUAL LEV. 4mA  
ACTUAL LEV. 20mA  
RELAY

MEDIUM 1.3



SOLIDS  
►LIQUIDS  
LIQUIDS PIPE

## 7.1.4 FILTER COEFFICIENT

Position the ► cursor on FILTER COEFFICIENT, press  to enter

1  
SET DISTANCE 4mA  
SET DISTANCE 20mA  
MEDIUM  
► FILTER COEFFICIENT  
BLIND DISTANCE  
ACTUAL LEV. 4mA  
ACTUAL LEV. 20mA  
RELAY

Enter a value from 1 to 99. 1 maximum speed, maximum 99 slowness.  
0 excludes the filter making the immediate response

Use  and  to modify the value.

Press  to confirm.  to exit without changes

Default value: 20

1.4  
FILTER COEFF.

20

## 7.1.5 BLIND DISTANCE

Position the ► cursor on BLIND DISTANCE, press  to enter

1  
SET DISTANCE 4mA  
SET DISTANCE 20mA  
MEDIUM  
FILTER COEFFICIENT  
► BLIND DISTANCE  
ACTUAL LEV. 4mA  
ACTUAL LEV. 20mA  
RELAY

Represent the "BLIND ZONE" of the sensor. Input the desired value in order to avoid measures near the surface of the sensor (if necessary).

The minimum value is 250mm (5m vers.) or 400mm (8m vers.)

Use  and  to modify the value.


Press  to confirm. OK TO CONFIRM

Default values: 250mm (range 5m) or 400mm (range 8m)

1.4  
BLIND DISTANCE

0290 mm

## 7.1.6 ACTUAL LEV. 4mA


Position the ► cursor on ACTUAL LEV. 4mA, press  to enter  
Self distance learning function that is associated with the 4mA (lower value). Make sure that the level corresponds to 0%,

 to associate the actual measure with 4mA output value;

**OK TO CONFIRM . OK TO CONFIRM**

1  
SET DISTANCE 4mA  
SET DISTANCE 20mA  
MEDIUM  
FILTER COEFFICIENT  
BLIND DISTANCE  
► ACTUAL LEV. 4mA  
ACTUAL LEV. 20mA  
RELAY

## 7.1.7 ACTUAL LEV. 20mA

Place the ► cursor on ACTUAL LEV. 20mA, press  to enter  
Self distance learning function that is associated with the 20mA (lower value). Make sure that the level corresponds to 100%,

 to associate the actual measure with 20mA output value;

**OK TO CONFIRM . OK TO CONFIRM**



1  
SET DISTANCE 4mA  
SET DISTANCE 20mA  
MEDIUM  
FILTER COEFFICIENT  
BLIND DISTANCE  
ACTUAL LEV. 4mA  
► ACTUAL LEV. 20mA  
RELAY

## 7.1.8 RELAY

Position the ► cursor on RELAY, press  to enter

1  
SET DISTANCE 4mA  
SET DISTANCE 20mA  
MEDIUM  
FILTER COEFFICIENT  
BLIND DISTANCE  
ACTUAL LEV. 4mA  
ACTUAL LEV. 20mA  
► RELAY

In this sub-menù it's possible to setup onboard relays  
RL1 can be set as threshold relay or pump-control relay;  
RL2 can be set as threshold relay or diagnostic relay.

With the  button you can select the operation mode,  
then pressing  to confirm the selection

1.6  
SET RELAYS MODE


► RL 1 THRESHOLD  
RL 2 THRESHOLD  
RL 1 PUMP  
RL 2 DIAGNOSTIC





## 7.1.8.1 RL1 THRESHOLD (RL2 THRESHOLD equivalent)

Position the ► cursor on RL1 THRESHOLD, press  to enter

In this submenu you can set the set-point and the relay 1 and 2 action type (only 4-wires versions).



With the  button you can select the parameter to be programmed.

Press  to confirm.



### 7.1.8.1.1 VALUE



Position the ► cursor on VALUE, press  to enter

It's possible to input the threshold value that corresponds to the distance in mm from the sensor. Use  and  to modify the value.

Press  to confirm.  to exit without changes

Default value: 0000mm

**NB**-RL1 inactive with 0000mm



### 7.1.8.1.2 MIN/MAX


Position the ► cursor on MIN/MAX, press  to enter

It's possible to select if the relay works as maximum level threshold or minimum level threshold.

With the  button you can select the operation mode.

Press  to confirm.  to exit without changes



Default value: MAX for RL1; MIN for RL2



### 7.1.8.1.3 DELAY



Position the ► cursor on DELAY, press  to enter

It's possible to select the activation delay for the selected relay, from 0 to 99 sec.


Use  and  to modify the value.

Press  to confirm.  to exit without changes

Default value: 00s



## 7.1.8.1.4 SAFETY

Position the ► cursor on SAFETY, press  to enter  
A "safety alarm" provides a "closed" contact with relay energized in normal condition (no alarm), the contact switches to "open":

- Alarm condition (eg overcoming MAX);
- In power failure case.

With the  button you can select the alarm mode.,

Press  to confirm.  to exit without changes

Default value: YES

1.6.1

VALUE  
MIN/MAX  
DELAY  
► SAFETY  
ENABLE/DISABLE

1.6.1.4


SAFETY  
► YES  
NO

## 7.1.8.1.5 ABILITA/DISABILITA

Position the ► cursor on ENABLE/DISABLE, press  to enter

Select ENABLE to activate relay threshold.

Select DISABLE to not activate relay threshold.

With the  button you can select the operation mode.

Press  to confirm.  to exit without changes

Default value: ENABLE

1.6.1

VALUE  
MIN/MAX  
DELAY  
SAFETY  
► ENABLE/DISABLE

1.6.1.5


ENABLE/DISABLE  
► ENABLE  
DISABLE

## 7.1.8.2 RL1 PUMP (solo per RL1)

Position the ► cursor on PUMP, press  to enter

A pump control functioning activation, with hysteresis, is possible

Two thresholds setting is required:  
upper and lower threshold.

With the  button you can select the parameter to be programmed,

Press  to confirm.

1.6

SET RELAYS MODE  
RL 1 THRESHOLD  
RL 2 THRESHOLD  
► RL 1 PUMP  
RL 2 DIAGNOSTIC



1.6.2

► UPPER  
LOWER  
DELAY  
FILL./EMPT.  
ENABLE/DISABLE

### 7.1.8.2.1 UPPER

Position the ► cursor on UPPER, press  to enter

The upper threshold (see fig.33) is expressed in mm distance from the sensor. Represents the pump starting point, EMPTY case, or pump stopping point, FILLING case.

Use  and  to modify the value.

Press  to confirm.  to exit without changes

Default value: 0000mm


1.6.2



► UPPER  
LOWER  
DELAY  
FILL./EMPT.  
ENABLE/DISABLE

1.6.2.1

SET UPPER VALUE  
**0900mm**



## 7.1.8.2.2 LOWER

Position the ► cursor on LOWER, press  to enter  
The lower threshold (see fig.35) is expressed in mm distance from the sensor. Represents the pump stopping point, EMPTY case, or pump starting point, FILLING case.

Use  and  to modify the value.

Press  to confirm.  to exit without changes



Default value: 0000mm



## 7.1.8.2.3 DELAY



Position the ► cursor on DELAY, press  to enter

Set the relay delay activation, from 0 to 99 sec.

Use  and  to modify the value.

Press  to confirm.  to exit without changes


Default value: 00



## 7.1.8.2.4 FILL./EMPT.

Position the ► cursor on FILL./EMPT., press  to enter

it's possible to select the mode of pump control (FILLING or EMPTING).

With the  button you can select the operation mode.

Press  to confirm.  to exit without changes

Default value: EMPTING







Fig.33

## 7.1.8.2.5 ENABLE/DISABLE

Position the ► cursor on ENABLE/DISABLE, press  to enter

Select ENABLE to activate relay threshold.

Select DISABLE to not activate relay threshold.

With the  button you can select the operation mode.

Press  to confirm.  to exit without changes

Default value: DISABLE

1.6.2  
UPPER  
LOWER  
DELAY  
FILL./EMPT.  
►ENABLE/DISABLE


1.6.2.5  
ENABLE/DISABLE  
ENABLE  
►DISABLE

## 7.1.8.3 RL2 DIAGNOSTIC

Position the ► cursor on RL2 DIAGNOSTIC, press  to enter

If it becomes necessary the KTU5 functional control, it's possible to enable the RL2 alarm output function. In this case, enabling the function, RL2 is energized in normal operation (RL2 LED on) and is de-energized (LED RL2 off, safety alarm) when at least one of the four conditions mentioned below, shall be verified:

- TEMP. : temperature out of range
- ECHO : no echo is detected
- GAIN : the sensor's gain exceed the value setted in Max Gain TH (3.4)
- DIST. : the measured distance exceed the 120% of the maximum distance in setup


With the  button you can select the operation mode.

Press  to confirm.  to exit without changes

Default value: DISABLE

1.6  
SET RELAYS MODE  
RL 1 THRESHOLD  
RL 2 THRESHOLD  
RL 1 PUMP  
►RL 2 DIAGNOSTIC



1.6.3  
ENABLE/DISABLE  
ENABLE  
►DISABLE

**NOTE:** when an error occurs, a "!" is flashing on the display: press  to show a message that indicate what kind of error is present. The KTU5 automatically returns to RUN mode.

## 7.2 DISPLAY

From "RUN" mode, holding down , press  to access

Position the ► cursor on DISPLAY, press  to enter

Select the parameters by moving the cursor with  and confirm with 

SETUP  
►DISPLAY  
DIAGNOSTIC  
SERVICE  
INFO


2  
►DISPLAY VALUES  
ECHO MAP  
LCD CONTRAST  
WELCOME TEXT

### 7.2.1 DISPLAY VALUES

Position the ► cursor on DISPLAY VALUES, press  to enter

2  
►DISPLAY VALUES  
ECHO MAP  
LCD CONTRAST  
WELCOME TEXT

It's possible to select if one value with big digits or two values are shown on the display in "RUN" mode

With the  button you can select the parameter to be programmed.

Press  to confirm.  to exit without changes


2.1  
DISPLAY VALUES  
►1 VALUE  
2 VALUES




## 7.2.1.1 1 VALUE

Position the ► cursor on 1 VALUE, press  to enter

Only one value is displayed; it's possible to choose from 5 parameters.

With the  button you can select data to display.


Press  to confirm.  to exit without changes







## 7.2.1.2 2 VALUES

Position the ► cursor on 2 VALUES, press  to enter

Two values are displayed; it's possible to choose which one is the primary and which is the secondary, each with a choice of 5 parameters

With the  button you can select data to display

Press  to confirm.  to exit without changes





## 7.2.2 ECHO MAP

Position the ► cursor on ECHO MAP, press  to enter

Detailed function description on page 13, figure 32



 to exit and return to the menu 2



## 7.2.3 LCD CONTRAST


Position the ► cursor on LCD CONTRAST, press  to enter

it's possible to adjust the contrast of LCD, simply increasing or decreasing the value of a parameter from 0 to 63.

Use  and  to modify the value.

Press  to confirm.  to exit without changes





Default value: 32



## 7.2.4 WELCOME TEXT


Position the ► cursor on WELCOME TEXT, press  to enter

It's possible to edit or delete the message that is displayed by the KTU5 during the ignition phase.

Use  (up scroll) and  (down scroll) to change the digit;  to move the digit to the right. To confirm press  repeatedly until leave the parameter.

 to exit without changes



Default value: SGM-LEKTRA KTU5





## 7.3 DIAGNOSTIC

From "RUN" mode, holding down , press  to access

Position the ► cursor on DIAGNOSTIC, press  to enter


Select the parameters by moving the cursor with  and confirm with 



### 7.3.1 FALSE ECHO DETECT

Position the ► cursor on FALSE ECHO DETECT, press  to enter

**NB** - To use this parameter the tank *must strictly be empty*



It's necessary to input the empty distance (distance from the tank bottom)

Use and to modify the value.

Press to confirm. to exit without changes

"KTU5" automatically stores all echoes detected and implemented an echo true and any eventual spurious echoes automatic selection. After this, the following message is displayed: **FALSE ECHO DETECT PROGRES**  
After procedure completion, the following message is displayed:

**FALSE ECHO DETECT DONE**

If something is not correct (e.g. wrong empty distance value, obstacles that hides the bottom) the following message is displayed:

**FALSE ECHO DETECT ERROR**

Note: *False echo detect procedure is not recommended for pipe and stand-pipe applications*  
*To delete this function, need to restore the default parameters (see par. 7.4.5)*

3.1  
SET EMPTY DISTANCE  
**0000** mm

## 7.3.3 MEASURE STATUS

Position the cursor on MEASURE STATUS, press to enter

3  
FALSE ECHO DETECT  
▶ MEASURE STATUS  
FROZEN GAIN  
MAX GAIN TH.  
PEAK VALUES  
OUTPUT SIMUL.

It's possible to display the gain of the system, with values from 0 to 255.  
While displayed, the automatic gain control is not active

to exit

3.2  
MEASURE STATUS  
G : 00000

## 7.3.4 FROZEN GAIN

Position the cursor on FROZEN GAIN, press to enter

3  
FALSE ECHO DETECT  
MEASURE STATUS  
▶ FROZEN GAIN  
MAX GAIN TH.  
PEAK VALUES  
OUTPUT SIMUL.

It's possible to fix a value of gain (from 1 to 255) and consequently disable the automatic gain control. Once the value is 000 the automatic gain control restarts

Use and to modify the value.

Press to confirm. to exit without changes

Default value: 000

3.3  
FROZEN GAIN  
**000**

## 7.3.5 MAX GAIN TH

Position the cursor on **MAX GAIN TH**, press to enter

3  
FALSE ECHO DETECT  
MEASURE STATUS  
FROZEN GAIN  
▶ MAX GAIN TH.  
PEAK VALUES  
OUTPUT SIMUL.

It's possible to input a value of gain that it should be not reached in normal operation. If the gain exceeds this value, the "GAIN" error code is activated.

Use and to modify the value.

Press to confirm. to exit without changes

Default value: 255 (Max gain)

3.4  
MAX GAIN TH  
**255**


## 7.3.6 PEAK VALUES

Position the ► cursor on PEAK VALUES, press  to enter

3  
FALSE ECHO DETECT  
MEASURE STATUS  
FROZEN GAIN  
MAX GAIN TH.  
►PEAK VALUES  
OUTPUT SIMUL.

The system store the maximum distance and the minimum distance measured since the power is turned ON.

It's possible to see those values or reset the values

With the  button you can select the function.

Press  to confirm.


3.5  
►DISPLAY VALUES  
RESET VALUES

### 7.3.6.1 DISPLAY VALUES

Position the ► cursor on DISPLAY VALUES, press  to enter

3.5  
►DISPLAY VALUES  
RESET VALUES

Displays the max. and min. distance measured from power on.

 to exit.

**NB** - The peak values stored are erased every time the KTU5 turns-off

3.5.1  
PEAK VALUES  
MAX 0000mm  
MIN 0000mm


### 7.3.6.2 RESET VALUES

Position the ► cursor on RESET VALUES, press  to reset

 to return to the previous menu.



3.5  
DISPLAY VALUES  
►RESET VALUES


## 7.3.7 OUTPUT SIMULATION

WARNING - entering in the SIMULATION function, the current output is not in function of the level measurement. To restore the current as a measured level function, press the  button 3 times (RUN mode)

Position the ► cursor on OUTPUT SIMULATION, press  to enter .

It's possible to force the analog output to a desired value.

Use  and  to modify the value.


Press  to return to the previous menu.

3  
FALSE ECHO DETECT  
MEASURE STATUS  
FROZEN GAIN  
MAX GAIN TH.  
PEAK VALUES  
►OUTPUT SIMUL.



3.6  
OUTPUT SIMUL.  
00.0 mA



## 7.4 SERVICE

From "RUN" mode, holding down , press  to access

Position the  cursor on SERVICE, press  to enter

Select the parameters by moving the cursor with  and confirm with 

SETUP  
DISPLAY  
DIAGNOSTIC  
▶SERVICE  
INFO

▶OUTPUT SAFE MODE  
SET UID  
LANGUAGE  
FREQUENCY  
F. WINDOW  
RESTORE SETTINGS

### 7.4.1 OUTPUT SAFE MODE


Position the  cursor on OUTPUT SAFE MODE, press  to enter

It's possible to choose a analog output value durin diagnostic errors.

"**21.5 mA**" forces the current output to 21,5mA

"**3.85 mA**" forces the current output to 3,85mA

"**HOLD LAST VALUE**" maintains the output at the last valid value.

With the  button you can select the operation mode.

Press  to confirm.  to exit without changes

Default value: HOLD LAST VALUE



▶OUTPUT SAFE MODE  
SET UID  
LANGUAGE  
FREQUENCY  
F. WINDOW  
RESTORE SETTINGS

OUTPUT SAFE MODE  
▶21.5 mA  
3.85 mA  
HOLD LAST VALUE

### 7.4.2 SET UID

Position the  cursor on SET UID, press  to enter

Can assign the address UID in this parameter, for a MUDBUS RTU network

Use  and  to modify the value.

Press  to confirm.  to exit without changes

Default value: 001

▶OUTPUT SAFE MODE  
SET UID  
LANGUAGE  
FREQUENCY  
F. WINDOW  
RESTORE SETTINGS

SET UID  
**001**

### 7.4.3 LANGUAGE

Position the  cursor on LANGUAGE, press  to enter

Sets the menu language: English, Italian, French

Press  to select the menu language.

Press  to confirm.  to exit without changes


▶OUTPUT SAFE MODE  
SET UID  
LANGUAGE  
FREQUENCY  
F. WINDOW  
RESTORE SETTINGS

LANGUAGE  
▶ENGLISH  
ITALIANO  
FRANCAIS

## 7.4.5 CHECK FREQUENCY

Position the ► cursor on CHECK FREQUENCY, press  to enter

It's possible to check the computed sensor emission frequency

 to exit

4  
OUTPUT SAFE MODE  
SET UID  
LANGUAGE  
►FREQUENCY  
F. WINDOW  
RESTORE SETTINGS

4.5  
FREQUENCY

00.0 kHz

## 7.4.6 F. WINDOWS

Position the ► cursor on F. WINDOWS, press  to enter

Refer to figure 32 on page 13 .The F.WINDOW is the sensitive area width around the true echo. All echoes detected inside the F.WINDOW are valid. F.WINDOW automatically centers itself in the most probable echo neighborhood and automatically adjusts its width (step). The step value of the window, expressed in cm, is represented by SET WIDTH; for example: parameter set to 5; the sensor is hooked to a 4m distant signal echo; suddenly the echo signal disappears and a echo signal is detected to 1m; KTU5 will start to open the search range with steps of 5cm at each echo signal emission, so to cover the 3 meters that separate the 4m distant signal echo by the new 1m distant echo, KTU5 will take 60 emissions to reach the new 1m distance eco. This parameter serves to filter false echo signals products, for example, by the agitator blades. Range: 00÷20

Press  to confirm.  to exit without changes

Default value: 05

4  
OUTPUT SAFE MODE  
SET UID  
LANGUAGE  
FREQUENCY  
►F. WINDOW  
RESTORE SETTINGS

4.6  
SET WIDTH

00

## 7.4.5 RESTORE SETTING

Position the ► cursor on RESTORE SETTING, press  to enter

Press  to restore the KTU5 default settings

 to exit without restored the KTU5 default settings.


4  
OUTPUT SAFE MODE  
SET UID  
LANGUAGE  
FREQUENCY  
F. WINDOW  
►RESTORE SETTINGS

4  
OK TO CONFIRM

## 7.5 INFO

Position the ► cursor on INFO, press  to enter

In addition to information about the manufacturer, are displayed the firmware revision and the configuration index.

 to exit.

SETUP  
DISPLAY  
DIAGNOSTIC  
SERVICE  
►INFO

5  
SGM-LEKTRA  
KTU5  
FIRMWARE REV. 1.01  
I.C 1.1.01

[illegible]

---

**SGM-LEKTRA S.r.l.** Via Papa Giovanni XXIII, 49 - 20090 Rodano (MI) - ITALY-  
**tel:** ++39 0295328257 **fax:** ++39 0295328321  
**web:** [www.sgm-lektra.com](http://www.sgm-lektra.com) **e-mail:** [info@sgm-lektra.com](mailto:info@sgm-lektra.com)